AXSWC | Button Remapping

After the AXSWC interface has been programmed and is functioning properly, button assignments for the steering wheel controls may be reassigned.

> **NOTE**
> (**Example**) Remap the **Seek Down** button to function as the **Mute** button.

Button Remapping Methods

Button Remapping can be achieved:

1. By following the steps below.
2. Via a Windows-based computer using the Axxess Updater.
3. Via the Axxess Updater app available from the Android or Apple mobile devices App Stores.

> **TIP**
> Apple mobile devices will require the use of the AXHUB-1 for this feature

Button Remapping Procedure

Follow the steps below to remap SWC buttons:

> **WARNING**
> If more than twenty (20) seconds elapse between any step below, the remapping procedure will abort, and the LED on the interface will go out. The interface may not function properly and must be reset and reprogrammed.

1. Cycle the ignition **On** and wait until the LED flashes **Green** once, then goes out. (**continued on Page 2.**)



Button Remapping Procedure (cont.)

2. Immediately press and hold **Volume Up** on the steering wheel until the LED turns solid **Green**, then release. The LED will then go out, indicating **Volume Up** has been programmed.



3. Press and hold **Volume Down** on the steering wheel until the light turns solid **Green**, then release. The LED will then go out, indicating **Volume Down** has been programmed.



4. Continue from **Seek Up/Next** in the **Button Function Legend** below to reference the order in which the steering wheel control buttons must be programmed. (**continued on Page 3**)

> **NOTE**
> If a function in the legend is not present on the steering wheel, press **Volume Up** on the steering wheel until the LED turns solid **Green**, then release. This will force the interface to skip that function.

Button Remapping Procedure (cont.)

5. Press and hold **Volume Up** on the steering wheel until the LED turns solid **Green**, then goes out.



6. Release **Volume Up**.

The remapping process is complete.

Button Function Legend

Number	Function	Number	Function
1	Volume Up	10	Band
2	Volume Down	11	Play/Enter
3	Seek Up/Next	12	PTT (Push to Talk)
4	Seek Down/Prev	13	On Hook
5	Source/Mode	14	Off Hook
6	Mute	15	-
7	Preset Up	16	-
8	Preset Down	17	-
9	Power	18	-

NOTE

Certain radios may not feature all commands. Please refer to the manual provided with your radio, or contact the Radio Manufacturer for specific commands recognized by that radio.