UMBRA&

Charging Information

Charging instructions for the Somfy Sonesse 30 Wirefree RTS motor when being used with Umbra blind systems.

IF THE CHARGING CABLE IS VISIBLE

1. Using the Somfy charger, connect the charger to the charging cable. This will be on the drive end of the motor.
2. When the charger is connected an LED light will come on, when you begin charging it will be red, it will turn orange when it's nearly finished charging and when it is fully charged the light will turn green.
3. When the LED light is green and motor is fully charged, disconnect the charger and store away for future use.

IF THE CHARGING CABLE IS NOT VISIBLE

1. If the motor and charging cable are hidden inside a headbox, you must first remove the front cover so that the motor is visible.
2. On our Helios Cassette, Kuro and KuroLok products, you will first have to remove a screw at either end of the cassette to do this.
3. On our Sirios Cassette, there is a screw at either end of the front cover. Remove these and keep safe. Then you can just lift the cassette up and it should come off easily.
4. Once the front cover has been removed, locate the charging cable at the drive end of the motor.
5. Using the Somfy charger, connect the charger to the charging cable.
6. When the charger is connected an LED light will come on, when you begin charging it will be red, it will turn orange when it's nearly finished charging and when it is fully charged the light will turn green.
7. When the LED light is green and motor is fully charged, disconnect the charger and store away for future use.
8. Put the cassette back on the blind and ensure it's in the correct place. If the cassette had locking pins, these now need to slide back to their original position to secure the cassette in place. Place any screws you removed back in the cassette.

T: 01792 562015
E: sales@umbrashading.co.uk